

Elevation (1:25)







Item:	Description:	Specified:	
1	Glass	12mm Fire Glass GFP12-60/0	
2	Seal	Neutral silicone capping	
3	Gasket	12 x 5mm closed cell foam tape	
4	Fixing	50mm steel screws at 250mm centres (30° to glass)	
5	Packer	Non-combustable setting blocks	
6	Bead	44x27mm timber bead, counterbored, screwed, then timber plugged	
7	Liner	104x32mm timber liner, minimum density 640 kg/m ³	
8	Mastic	FD60 Intumescent mastic	
9	Intumescent	54 x 2mm Palusol	

Drawing Checked & Approved By

_	Signed	Company	Date	ate		
					Client	
_					Site	
					0.10	






forza-doors.com
01403 711 126
sales@forza-doors.com





Notes:

- 1 All joints to be sealed using non-thermally softening adhesive.
- 2 Do not allow any contact of the glazing's edge with water.
- 3 Do not install in locations where the glass temperature in normal circumstances might exceed 45° C.
- 4 Avoid all glass to metal contact.
- 5 Do not exercise any restraint on the glazing.
- 6 Do not damage the glazing's edges nor the protection tape.
- 7 Keep the rebates dry and free from agressive products (acids, organic solvents, etc.).
- 8 Use 4mm thick non-combustable setting blocks at base.
- 9 Provide clearances of 5mm from glass edge to all peripheral framework.
- 10 Provide clearance to the beads, using designated gasket.
- 11 Apply a neutral silicone sealant immediately after glazing.
- 12 Frames fix to supporting construction at 600mm centres on jambs and head, min 200mm from ends. 75mm screws min.
- 13 Gap between frame and supporting construction should be sealed with suitable (FD60) mastic.



Drawing Checked & Approved By

Signed	Company	Date
	I	I
Client		
Site		

Title	Sidelight ElevationJ						
Code	FD60/0 - GFP12						
Sheet	2 of 2	Date	08/02/2013				
Issue	2	Dwg No	FZD0389				

